



Cap Assembled to Tubing

Assembly Instructions:

1. Insert tube into cap.
2. Follow standard HOKE Gyrolok assembly instructions, page 53.

Cap: CP

caps end of fractional tube

Part Number*	T Tube O.D.	Dimensions — inches				
		A	B Hex Flat	C Hex Flat	D	G
1CP []	1/16	.66	5/16	5/16	.41	.44
2CP []	1/8	.91	7/16	7/16	.56	.53
3CP []	3/16	.89	1/2	7/16	.59	.58
4CP []	1/4	.95	9/16	1/2	.64	.63
6CP []	3/8	1.06	11/16	5/8	.72	.72
8CP []	1/2	1.28	7/8	13/16	.97	.81
10CP []	5/8	1.33	1	15/16	1	.89
12CP []	3/4	1.36	1 1/8	1 1/16	1	.92
14CP []	7/8	1.41	1 1/4	1 3/16	1.06	.97
16CP []	1	1.77	1 1/2	1 3/8	1.31	1.20
20CP []	1 1/4	2.10	1 7/8	1 3/4	1.53	1.23
24CP []	1 1/2	2.54	2 1/4	2 1/8	1.78	1.47
32CP []	2	3.41	3	2 3/4	2.47	1.94

Tube Cap: CP/MM

caps end of metric tube

Part Number*	T Tube O.D.	Dimensions — mm				
		A	B Hex Flat	C Hex Flat	D	G
3CP [MM]	3	22.8	11.1	11.1	14.3	14.8
4CP [MM]	4	23.6	12.7	11.1	15.1	15.8
6CP [MM]	6	25.3	14.3	12.7	16.3	16.9
8CP [MM]	8	25.1	15.9	14.3	16.7	17.1
10CP [MM]	10	26.2	19.1	17.5	17.5	18.3
12CP [MM]	12	32.6	22.2	20.6	24.6	20.6
14CP [MM]	14	31.6	23.8	22.2	22.2	22.2
15CP [MM]	15	31.9	23.8	22.2	22.2	21.5
16CP [MM]	16	35.0	25.4	23.8	25.0	23.9
18CP [MM]	18	33.4	28.6	27.0	25.4	23.4
20CP [MM]	20	40.0	31.8	30.2	31.0	25.2
22CP [MM]	22	35.8	31.8	30.2	27.0	24.6
25CP [MM]	25	45.9	38.1	34.9	33.3	31.5
30CP [MM]	30	53.4	50.8	46	39.6	31.8
32CP [MM]	32	55.8	50.8	46	42	32.8
38CP [MM]	38	65.4	60.3	55	49.4	37.8